User's Manual

Model DXA200
DAQEXPLORER

Notice of Alterations

Please make the following alterations to your user's manual.

Page 2-2 DAQ Desktop Functions

Page 2-8 DAQ Desktop Functions

- Display data file (*.dds and *.cds)
- Event data file (*.dev and *.cev)

Page 4-2 Files that launch the Data Viewer

- : Display data file (*.dds and *.cds)
- : Event data file (*.dev and *.cev)

Page 4-16

When linking and displaying files, make sure that the number of data points after linking does not exceed 5000000. In addition, if there is a period over which data does not exist such as when a power failure occurs, data is counted as if the data is acquired at the given scan interval even during that period. The scan interval and the maximum period for linking files are indicated below.

Interval	Period
1/8 s	7.23 days
1 s	57.9 days
10 s	18.7 months
60 s	9.51 years
10 min	95.1 years

For example, if data is acquired continuously at 1-s scan interval and there is a period of power failure over 57.9 days, the data before and after the power failure cannot be linked and displayed.

Page 4-19

For the alarm list or the event list, click a label to sort using the label. The first click will sort the list in the ascending order; the second click will sort the list in the descending order.

Page 6-18

Switching Hysteresis

Specify the switching hysteresis value with the measurement input span EUS (0.0 to 10.0%). With style number S1 (system setting), it is not displayed if the PID number is 2 or less. With style # S2, it is not displayed when the PID number is 1 or less.

Reference Deviation

Turn the reference deviation on or off, and specify the value with the measurement input span one-digit EUS (100.0%). It is not displayed when the PID number is 2 or less.

Page 6-24 Initial Program Paterns(Initial Setting)

Event output and AUX settings cannot be copied or pasted with the Copy and Paste buttons.

Page 6-25 Program Patern Setting(Segment setting)

The Initialize button does not initialize the default settings, event output settings, or AUX settings.

Page 6-28